

ADEKA ULTRA SEAL MC-2010MN

General Installation Procedures

Waterstop wall/slab joint

Place a small bead of Adeka Ultra Seal P-201 on any rough or scarred area prior to attaching MC-2010MN.

Attach MC-2010MN to the concrete by one of the following methods:

1. Attach with nails or concrete screws placed every 10" ~ 12" (approximately). If the concrete is rough, apply P-201 prior to attaching MC-2010MN.

Smooth, clean and dry concrete:

2. Use a fast setting rubber adhesive
Example - 3M-2141, Bostik 1142M to fasten MC-2010MN to concrete. Follow adhesive manufacturers recommendation.

3. Use Adeka Ultra Seal P-201 on rough concrete. P-201 can be used on vertical or overhead rough concrete when fastened with screws or nails.

Site conditions may warrant the use of a combination of attachment methods. Use P-201 on all corner joints and parallel splices.

Keep MC-2010MN taut and flat against the concrete during the attaching process. Do not allow any gap between the concrete and the MC-2010MN.

*** NOTE:** MC-2010MN must be placed between two rows of rebar. The required concrete coverage varies from 4" ~ 5" depending on concrete strength.

For complete coverage information see reverse side or see MC Coverage Chart at www.adeka.com

