



No. 1: For P-201 repair - cut a notch 1/2" X 2" deep

No. 2: For P-201 repair - apply a continuous bead of P-201 to a depth of 1/2". Place oversized backer rod against P-201. Fill remaining void with grout, epoxy or other joint filler material.

Not to scale